FRS Radio Quick Guide

This is used by the Palo Alto Medical Foundation. They have these instructions plasticized and tied to each of their FRS radios.

How To Use Walkie Talkies



- Hold 2-5 inches from your mouth.
 This will allow your voice to be heard clearly.
- Set radio to Channel | , Mode 1 (if it's not already set).
 - 1 Turn radio on.
 - 2 Press Menu once. The current channel displays and flashes.
 - 3 Press + or to select channel].
 - 4 Press the PTT button on the side to save the Channel 1 setting.
 - 1 To change Mode, press Menu twice. The Mode number will flash.
 - 2 Press + or to select Mode 1.
 - 3 Press the PTT button on the side to save the Mode 1 setting.

Other NPC/BPCs have placed labels on the back of their FRS radios to indicate their neighborhood call sign name (Midtown 2) their channel and sub channel (channel 8, sub-channel 11)